



Nikon LENS - PORT - CHART 2014/2

NIKON Lens	Housings	D i o p t e r	Zoom Gear operated with manual Focus control in SUBAL F5/N10/N80 SUBAL D10/FS2 SUBAL ND2/ND20	Zoom Gear operated with manual Focus control in SUBALND3/ND4/S ND30/ND90 ND300 ND600/ND700 ND7000/ND7100 ND800/810	Focus Gear in SUBAL F5/N10/N80 SUBAL D10/FS2 SUBAL ND2/ND20	Focus Gear in SUBAL ND3/ND30 SUBAL ND700/ND90 ND7000/ND7100 ND800/ND810
AFDX 10,5 /2.8G ED	DP-FE DP-100	n.a.			4FN051 4FN751	4FN351
MF 16 / 2.8	DP-FE	n.a.			4FN014	
AF 16 / 2.8 D	DP-FE	n.a.			4FN050 universal: 4FN350	universal: 4FN350 4FN850
AF 14 / 2.8 ED	DP-FE + EXR20 DP-230 + EXR20	n.a.			AF only	AF only
AF 18 / 2.8 D	DP-SWB DP-FE + EXR15 DP-230 + EXR15	+4/77 +2/77 +2/77			4FN016	
AF 20 / 2.8 D	DP-SWB DP-FE	+4/62 +2/62			4FN001 4FN701 (in ND70) 4FN801	4FN301
AF 24 / 2.8 D	DP-SWB DP-FE	+4/52 +2/52			4FN027	
AF 24 / 1.4 G ED	DP-FE + EXR40 DP-230 + EXR40	+2/77			4FN835	
AF 28 / 2.8 D	DP-SWB DP-FE	+4/52 +2/52			4FN027	
AF 35 / 1.4 G	DP-100 + EXR 33 DP -FE + EXR 33					
AF 35 / 2 D	DP-SWB DP-FE	+4/52 +2/52			4FN034 4FN334	
AF 50 / 1.4 G	DP-FE FP 55					
AF 60 / 2.8 D micro	FP-90				4FN006 4FN706 (in ND70)	4FN306
AF-S 60 / 2.8 G ED micro	FP-75				4FN362 (universal, also in ND20/ND70)	4FN362 4FN862
AF-S 85 / 1.4 G	FP 55					
AF-S 85 / 3.5 G ED micro	FP-90				universal: 4FN365	universal: 4FN365 4FN865
AF 105 / 2.8 D	FP-120 FP-FC60+EXR33 FP-FC105				AF only 4FN15F (focus g.) gears included	AF only 4FN15F (focus g.) gears included
AF-S 105VR / 2.8 G ED	FP-FC105 VR FP-120VR (w/o. Focus)					
AF 200 / 2.8 D	FP-120 + EXR65 FP-FC105 + EXR65				4FN200 (with FP-FC105 only)	
AF-S DX 10-24 / 3.5-4.5G ED	DP-FE + EXR50 DP-230 + EXR50	+2/77 +2/77	4ZN333 identical!	4ZN333 identical! 4ZN833		

NIKON Lens	Housings	D i o p t e r	Zoom Gear	Zoom Gear	Focus Gear	Focus Gear
			operated with manual Focus control in SUBAL F5/N10/N80 SUBAL D10/FS2 SUBAL ND2/ND20	operated with man. Focus control in SUBAL ND3/ND4/S ND30/ND90 ND300 ND600/ND700 ND7000/ND7100 ND800/810	In	In
AF-S DX 12-24 / 4G IF-ED	DP-FE + EXR50 DP-230 + EXR50		4ZN100 (in ND20) 4ZN700 (in ND70)	4ZN300 4ZN800		
AF-S 14-24 / 2.8G ED	DP-FE4 + EXR65 DP-230/4 + EXR65 DP-SUP + EXR65	n.a.		4ZN327 4ZN827		
AF-S 16-35 / 4.0G ED VR	DP-FE4 + EXR90 DP-230/4 + EXR90	+2/77 +2/77		4ZN034 4ZN834		
AF-S 16-35 / 4.0G ED VR	DP-FE4 + FXR90 DP-230/4 + FXR90	+2/77 +2/77				4FN890 Only with FXR!
AF-S DX 16-85 / 3.5-5.6G ED VR	DP-FE + EXR40 DP-230+ EXR40		4ZN032 identical! 4ZN732 (in ND70)	4ZN032 identical! 4ZN832		
AF-S 17-35 / 2.8 D	DP-SWB + EXR40 DP-FE + EXR60 DP-230+ EXR60 DP-SUP + EXR75	+4/77 +2/77 +2/77	4ZN023 identical! 4ZN723 (in ND70)	4ZN023 identical! 4ZN823	AF only	AF only
AF-S DX 17-55 / 2.8G IF-ED	DP-FE3 + EXR70N1 DP-FE4 + EXR70/4 DP-230/3 + EXR70N1 DP-230/4 + EXR70/4		4ZN026 (also in ND70)	4ZN326 4ZN826		
AF-S DX 18-70 / 3.5-4.5G IF-ED	DP-FE + EXR20 DP-230 + EXR20	+2/67 +2/67	4ZN101 4ZN701 (in ND70)	4ZN301		
AF 18-35 / 3.5-4.5 D	DP-SWB + EXR33 DP-FE + EXR40 DP-230 + EXR40	+4/77 +2/77 +2/77	4ZN021 identical! 4ZN721 (in ND70)	4ZN021 identical! 4ZN821		
AF-S DX 18-55 / 3.5-5.6 G VR	DP-SWB + EXR33 FP-90 /4	+4/52		4ZN835		
AF 20-35 / 2.8 D	DP-SWB + EXR33 DP-FE + EXR40 DP-230 + EXR40	+4/77 +2/77 +2/77	4ZN014 4ZN714 (in ND70)	4ZN314	AF only	AF only
AF 24-50 / 3.3-4.5 D	DP-SWB + EXR20 DP-FE + EXR33 DP-230 + EXR33	+4/62 +2/62 +2/62	4ZN008	4ZN008 identical!	4FN028	
AF-S 24-70 / 2.8G ED	DP-FE + EXR100 DP-230 + EXR100	+2/77 +2/77	4ZN328 universal	4ZN328 universal 4ZN828		
AF 24-85 / 3.5-4.5 G	DP-SWB + EXR15 DP-FE + EXR20 DP-230 + EXR20	+4/67 +2/67 +2/67	4ZN025 4ZN725 (in ND70)	4ZN325	AF only	AF only
AF 24-85 / 2.8-4 D	DP-FE + EXR33 DP-230 + EXR33	+2/72 +2/72	**)	4ZN831	AF only	AF only
AF-S VR 24-120 / 3.5-5.6G IF-ED	DP-FE + EXR50 DP-230 + EXR50	+2/72 +2/72		4ZN829		
AF-S 28-70 / 2.8 D	DP-FE3 + EXRS70 DP-FE4 + EXR70/4 DP-230/3 + EXRS70 DP-230/4+ EXR70/4	+2/77 +2/77 +2/77 +2/77	**)	4ZN830	AF only	AF only
AF 28-80 / 3.5-5.6 D 0,4m	DP-SWB + EXR15 DP-FE + EXR33 DP-230 + EXR33	+4/58 +2/58 +2/58	4ZN019		AF only	AF only
AF 28-80 / 3.3-5.6 G 0,35m	FP-68B DP-SWB + EXR15 DP-FE + EXR33 DP-230 + EXR33	+4/58 +2/58 +2/58	4ZN009 4ZN709 (in ND70)		AF only	AF only
AF 28-85 / 3.5-4.5	FP-102B DP-122 DP-FE + EXR60 DP-230 + EXR60	+4/62 +2/62 +2/62 +2/62	4ZN007 4ZN707 (in ND70)		4FN110	
AF 28-105 / 3.5- 4.5 D	DP-FE + EXR33 DP-230 + EXR33	+2/62 +2/62	4ZN024	4ZN024		
AF Micro 70-180 / 4.5-5.6 D ED	FP-120 + EXR65		4ZN022 4ZN722 (in ND70)	4ZN322 4ZN822		
	FP-FC105 +EXR65		4ZN022 4ZN722 (in ND70)	4ZN322 4ZN822	4FN718F	

\*) needed if a FOCUS lens gear is used too

\*\*) operated with focus cogg gear directly on the lens rubber barrel

GEARS FOR OLDER LENSES ON REQUEST!

ERRORS EXCEPTED!

Updated13.08.2014