



Features on frontpart

- 1 Shutter Release
- 2 Focus/Zoom
- 3 Focus Mode Selector
- 4 AF-Mode Button
- 5 Lens Release Button
- 6 Power Switch
- 7 Port-Lock
- 8 Sub Command Dial
- 9 Mode Dial
- 10 Lock Release Button
- 11 Release Mode Dial
- 12 Flash Mode Button
- 13 Metering Button
- 14 Exposure Comp. Button
- 15 Flash Close
- 16 Bracketing Button

Features on Back

- 17 Play Back Button
- 18 Delete Button
- 19 Menu Button
- 20 White Balance
- 21 ISO Button
- 22 Quality Button
- 23 AE-L/AF-L Button
- 24 Main Command Dial
- 25 LiveView Switch
- 26 Movie Record Button
- 27 OK Button
- 28 Multi Selector Buttons
- 29 Info Button

Optional

- 4 Viewfinder Systems
- Bulkheads
- SEA&SEA Ports for Fibre
- Cable Plug

SUBAL austria
 ND7000 housing
 for Nikon D7000